

NOSAČ TIP N1		OBUJMICA		NOSAČ TIP N2		NOSAČ SA KRUŠKASTOM OBUJMICOM		FERUM ANKER TIP FC		PREĆNIK CJEVOVODA									
										DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200	
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200
										MAKS. RASTOJANJE IZMEĐU OSLONACA (M)	2.8	3.1	3.3	3.5	4.5	5	5.5	5.5	6
										PREĆNIK CJEVOVODA	DN 25	DN 32	DN 40	DN 50	DN 65	DN 80	DN 100	DN 150	DN 200